

[How to Do Sampling Before Air Jet Sieve Analysis?](#)

- ◇ Take a sample which is representative of the sample as delivered and of sufficient size to permit the determination of the size distribution.
- ◇ Generally, for resin sample 25 g shall be used for each sieve analysis. For fine-particle such as resins, smaller quantities are more convenient, for example 10 g.

[HMK-200 Air Jet Sieving Machine](#)